

PROFESSIONAL RECORDING CANTILEVER BRACKET



1. After the base set into the bottom of the cantilever twist, Can be fixed with any plane fixation.



2. Microphone bracket rotating twisted into cantilever, head position for can, don't have to twist to the bottom.



3. The blowout stents into the microphone at the top of the golden screw parts. Will spray net twisted into the end of the stent, suits, nut don't have to remove.



4. Mobile phones support hose into cantilever bracket front-end interface, then put the nut twist.



5. Mobile phone stand clamp installation way



Let the roller set into the hose



Fixed the clamp, then set into metal hose



Rotating the rollers and fixed