

# Mechanical Pin Timer

# Instructions

**24 Hour**  
Programmable  
(Daily Cycle)

- 1) Locate an outlet that is close to the device that you desire to time.
- 2) The ON switch is located on the side of the unit and the grounded OUTLET as well.
  - a. UP position= AUTO timer
  - b. DOWN position= ON timer
- 3) Plug the timer unit into the wall outlet.
- 4) Setting the current time- by turning the spinner clockwise, align the arrow on the front of the unit to the current time. (The dial differentiates AM/PM by color: day or night).
- 5) Determine the desired start time by pushing down all pins until the desired finish time.
- 6) Plug your electrical device directly into the timer unit. The electrical device must be on the ON position for the controls to work properly.
- 7) In case of a power failure, reset the time of day as instructed in steps 2 and thereafter.

**⚠ WARNING****Risk of electric shock**

- Plug directly into an electrical outlet
- Do not use in wet locations
- Use indoors only
- Unplug timer before cleaning
- Keep children away

**Risk of fire**

- Do not use to control appliances that contain heating elements (cooking appliances, heaters, irons, etc.)
- Do not exceed electrical ratings